


DOWNLOAD AND CONNECT




STEP 1
Download the application from Google play or App Store. Direct access to download links can be found at myanywair.com




STEP 2
Visit the wireless settings section of your wireless device (smartphone, tablet or laptop) and connect to the network generated by your device (DEVICE_XXXXXX).


Wi-Fi CONFIGURATION




STEP 1
Select the Add Device icon in the bottom left corner of the screen to begin your setup.




STEP 2
Follow the on screen instructions and then press the "Start" button commence the configuration.




STEP 3
Once the screen displays your connected device, click the "Automatic" configuration button.



STEP 4
Select the desired Wi-Fi network you would like to connect the device to from those displayed on screen.



STEP 5
Enter your Wi-Fi password into the password field and then click "Connect".




STEP 6
The LED on the device will change colour according to it's stage in the configuration process. Once the device is successfully configured to the Wi-Fi network, the LED will turn off.


DEVICE REGISTRATION




STEP 1
Click the "Login" button.



STEP 2
Enter your username and password then press "Login".



STEP 3
Click the "+" symbol in the top right corner to add a device.




STEP 4
Click "OK" on the pop up.



STEP 5
If scanning the barcode, please ensure to use the barcode on the sticker, not on the unit. Alternatively, you can add the registration number by clicking "Manually".



STEP 6
If entering registration number manually, populate the fields then click "Add device".



STEP 7
Once device is added, click "OK" in the top left corner to complete.

How To Download And Connect

IR CONFIGURATION

STEP 1 Push the button on the rear of the device for 3 seconds.
The LED will turn white.

STEP 2 Pick up the infrared wireless remote control and push the On/Off button pointing to the device.



If configuration is **OK**, the device LED will blink green.



If configuration is **not OK**, the device LED will blink red.
Repeat the process from step 1 and check our compatibility*
list or visit myanywair.com for more details.




*For compatibility visit myanywair.com.

How To Download And Connect


POSITION DEVICE

There are several installation and placement options for the anywAiR technology Wi-Fi device. It can be installed side-by-side with the AC unit (case A), under the AC unit (case B), in front of the AC unit (case C) or on a desktop position (case D).




How To Download And Connect


ACCOUNT SETUP




STEP 1
Click the "Register" button.



STEP 2
Complete the form and press "Register"



STEP 3
Click the "OK" button.



STEP 4
Verify your account by clicking the url in the email.



STEP 5
Your account is now successfully activated.